

# Console Features



UNIVERSAL TERMINAL  
Enabled



CLOUD BASED SERVICES  
Disabled



ISOBUS SHORTCUT BUTTON  
Disabled



VDC SUPPORT  
Disabled



FILE SERVER  
Enabled



WEATHER STATION  
Unlicensed



CAMERAS  
Unlicensed



XTEND  
Enabled



PER POINT DATA  
Disabled

Also in System/Features/Console make sure the XTEND is Enabled



Licenses



Console



Guidance



Implement



XTEND



Wireless



Quick Start



Features



GPS



Serial Ports



Alarms



Flag Points



ISOBUS  
ISOBUS



Utilities



User



System



Vehicle



Implement



Product

# XTEND Settings



CONSOLE NAME  
BOURGAULT SERVICE

Device	Status	Action
SAMSUNG SM-G930W8	Disconnected	Forget

Go System/Features/XTEND  
see section 13 of the X35  
operators manual for  
instructions on set up and  
operation of the XTEND app.

The main menu consists of a grid of icons. The 'XTEND' icon is highlighted with a blue glow. A yellow arrow points from the 'XTEND' icon to the 'Features' icon. Another yellow arrow points from the 'Features' icon to the 'System' icon.